# To open the filter chamber



**Turn over** the Airpura



**Remove** the 4 retaining screws



Take off the cover



Remove the gasket



Position the Prefilter inside the filter chamber




**Place** a felt gasket at the bottom of the filter chamber



Unfold the filter slider (Supplied with replacement filters or on request Part#6F 001)



Roll it into a spiral



**Insert** the tube into the filter chamber inside the Prefilter



**Let** the spiral open to fill the opening



**Open** the top of the spiral to make a slight funnel



Insert the Carbon canister into the funnel and hold it straight



Let the canister slide down thefilter slider



Pull the filter slider up out of the cavity using both hands and let the canister slide to the bottom of the cavity



**Remove** the filter slider and fold it for further use



**Slide** in the Hepa filter

# 

# UV700

OPERATING & FILTER REPLACEMENT DIRECTIONS

# To close the filter chamber



**Replace** the gasket



Position the indentation in the cover into the center of the HEPA filter



**Replace** the 4 screws and tighten



**Turn** the Airpura back on casters

# TO BEGIN USING YOUR AIRPURA

**Inspect the exterior of your Airpura** to verify there is no damage from shipping. If any damage is noted, please follow the instructions from the distributor returns policy.

Wipe the unit with a damp cloth to remove any dust from packaging

1. Plug the unit into a regular grounded 110 volt outlet #l j oc i] Z V 'gej of Zgdc

Turn on the unit to MAX and allow it to run for at least 30 minutes

Set the variable speed control to the level you wish

The most efficient way to use your Airpura for regular air quality maintenance is to run it at a low speed 24 hours a day 7 days a week.

Always maintain a humidity level of approximately 40% to ensure the unit is operating at optimal levels. When using purifer with a dehumidifier, please keep dehumidifier at least 6 feet away. It is recommended to run your purifier at low speeds, 24 hours a day, 7 days a week. Running it at a low speed allows for maximum dwell time of chemicals and VOCs in the air through both the carbon and HEPA filters thus delivering superior filtration.



# FILTER MAINTENANCE AND REPLACEMENT

#### The Prefilter

Can be vacuumed from the exterior of the unit once a month or more often. Should be replaced at least after 12 months of use

#### To vacuum the Prefilter

Use the brush attachment on your vacuum cleaner Vacuum slowly around the mesh surface of the filter chamber

# **IMPORTANT SAFETY NOTE**

Please ensure air purifier is turned OFF when plugging into a power source. Failure to do so may result in motor potentially stalling and/or burning.


# Replacing the UV bulb

**Open** the filter chamber following the instructions

**Pull** the bulb upward out of the connector

**Push** the replacement bulb firmly into the connector


Close the filter chamber following instructions







18 lbs Coconut Shell Carbon Filter (100% blend) 24 months



**UV** bulb 18-20 months

# **Technical specifications**

# Tobacco smoke odor. and chemical control

18 lbs activated Carbon 13"H x 13.25"OD x 7.5"ID

# Carbon bed

2" deep

#### Particle removal

40 sq ft true HEPA (Measured 1 side only) 12 pleats per inch Pleats warm rolled with separators

### Air Flow 635 cfm

More cfm than any other home unit available

#### Housing

Powder coat steel

#### Size

23 in x 15 in

# Weight

45 lbs total

## Watts

120 on high / 40 on low

#### Sound Level

30.2\* db on low (at 6 feet) 63.0 db on high (635 cfm) \*at test conditions









Airpura Industries - 5510 Boul. des Rossignols, Laval, QC, Canada.

H7L 5W6

EPA Est.:100723-CAN-1